

## Running Boards Side Steps suitable for Audi Q7 4M (2016-2019) Off-Road SUV

Code RBA05C

---

To facilitate your installation, please read the product instruction manual carefully before installation.

**Step 1:** Remove the original side skirts of the car

**Step 2:** Place the brackets like in the picture below



**end left bracket**



**middle left bracket**



**front left bracket**



## Running Boards Side Steps suitable for Audi Q7 4M (2016-2019) Off-Road SUV

Code RBA05C

---

Mounting positions for the brackets



**end left bracket**



**middle left bracket**



**front left bracket**

After installation



**Step 3:** Adjust the place of the boards before tighten the screws

**Step 4:** Check whether all screws are tightened and pack the tools.

**Step 5:** Repeat on the other side

Disclaimer: Our company is not responsible for any related problems and losses caused by improper installation and use.