


Instructions for the removal of fastening belt, Z4025




Step 1 :

- 1-1 Take out the whole set of product acquired carefully .
- 1-2 Cut off the fastening belts (marked as pink circles in picture) and then remove the fastening bars, indicated by red arrows in the following picture



Step 2 :

- 2-1 Move away all the fastening belts and bars from the lamp-set, avoiding the loosened ones to fall inside the body of lamp-set.
- 2-2 The total no. of fastening belts and bars to be removed may vary from products of lamp-set



Step 3 :

- 3-1 After Step 1, 2 are followed and completed with care.
- 3-2 Put on the anti-dust cover to the marked area, shown as the following picture;(Actual no. of anti-dust covers may vary from products)



Step 4 :

- 4-1 The task is almost completed.
- 4-2 Make sure the anti-dust cover is fitted properly with certain tightness


VK129Z4 Installation Manual

Step 1




Tear down the dust-proof sticker.

Step 2



Cut off the two white cable ties and take them out.

Step 3



Remove the fixing iron hook.

Step 4



Put on the back cover and crew tight.

Step 5



Make the "Top" word position on up.

Step 6



Taped the IV to the place as the white arrow shows.